

Opti-1

ASSEMBLY INSTRUCTIONS for the Opti-1 ergonomic document holder



01 Put the document holder flat with the blank cardboard facing upwards. Fold the two external flaps as shown (green dots).




02 Raise the flaps 90° (green dots).



03 Fold them against the back (the side edges are raised)..



04 Hold the flaps in place and lift the lower section 90°.



05 Start folding the lower section while folding the two internal flaps (green dots).



06 Finish folding the lower section by pressing on the edge you have created.



07 Firmly close the edge and move the central flap (with the arches) towards you 90°.



08 Hold the central flap while folding the two side flaps inside.



09 Insert the tabs into the slots.



10 Fold the two external flaps as shown (green dots).



11 Lift then fold the flap against the back of the document holder.



12 Push the flap against the arches.



13 Fold the two side flaps towards the inside. Insert the tabs into the slots.



14 Turn the document holder over and press lightly on the edges to finish assembly.



15 Your document holder is ready for use. The user instructions are shown on the back.



Place the document holder directly onto your work surface (if necessary remove anything in the way, such as a calendar, etc). Run any cables there may be under the document holder arches. Do not forget to fold away the feet at the back of your keyboard.

We hope you enjoy working with the benefit of the Opti-1!

Watch the assembly how-to video here:

<https://www.optimeo-prevention.com/opti-1-montage> or scan the QR code shown opposite.

CONTACT US TO ORDER

☎ +33 (0)6 95 11 37 68

✉ contact@optimeo-prevention.com

www.optimeo-prevention.com